


P7 Ring Plier



OPERATING INSTRUCTIONS

1. Fasteners: This tool uses Ring Type 616 Staples.

2. Loading Instructions: For quick loading, hold P7 Ring Plier with magazine side upwards. Press in the core latch release at end of magazine with the thumb of the other hand, placing forefinger of free hand on the raised latch and pull core back (see Diagram A), which opens ring magazine. Insert ring stick in magazine, push core back toward nose of pliers to lock (see Diagram B).

